

-12V
 AGND
 IS2
 +12V
 -12V
 AGND
 IS1
 +12V
 TSDQ
 TGND
 T+3V

ONLY FOR CERTIFIED SENSORS
 0 - 400VDC HAZARDOUS NON-ISOLATED VOLTAGE EXISTS

31
 91
 32
 71
 33
 41
 34
 18
 35
 36
 37
 19
 38
 20
 39
 66
 40
 12
 41
 42
 43
 22
 44
 23
 45
 46
 47
 24
 48
 49
 25
 50
 26
 51
 27
 52
 28
 53
 27
 54
 28
 55
 29
 56
 29
 57
 30
 58
 30
 59

HAZARDOUS VOLTAGE EXISTS AT BATTERY TERMINALS, TEST LEADS AND CONNECTORS

● STATUS

BATTERY DAQ MODULE

WWW.BATTERYDAQ.COM

MADE IN USA

ALWAYS USE CAUTION WHEN WORKING ON BATTERIES

HAZARDOUS VOLTAGE EXISTS AT BATTERY TERMINALS, TEST LEADS AND CONNECTORS

30
 29
 28
 27
 26
 25
 24
 23
 22
 21
 20
 19
 18
 17
 16
 15
 14
 13
 12
 11
 10
 09
 08
 07
 06
 05
 04
 03
 02
 01
 01
 02
 03
 04
 05
 06
 07
 08
 09
 10
 11
 12
 13
 14
 15
 16
 17
 18
 19
 20
 21
 22
 23
 24
 25
 26
 27
 28
 29
 30

1-WIRE MODE
 2-WIRE MODE

PSEN RESET

ISOLATION BARRIER

POWER

RS485B
 RS485A
 GND
 RXD
 TXD
 RXD
 TXD
 GND
 GND
 +2V
 L/L
 RM EN
 ALARM
 GND

10500 (mil)
 Board Dimension on Mechanical4 Layer 4250 X 10500